

MAINTENANCE INSTRUCTIONS (continued)

LIME AND SCALE CLEANER INSTRUCTIONS

Wells Lime and Scale Cleaner for Warmer Pans
(instructions modified for used in Hot and Cold Pan)

NOTE: Perform weekly, or whenever lime or scale is seen accumulating on the sides of the tank.

1. Add water to tank until water is at normal operating level or until water covers accumulated scale.
2. Turn SELECTOR SWITCH to HOT. Heat water to maximum temperature (190°F or higher).
3. For AFCHCP-2, use two packages, -3 use 3 packages, -4 use 4 packages, -5 use 5 packages, -6 use 6 packages: Pour contents packages into tank. Stir to dissolve cleaner. Cover tank.
4. Allow solution to soak at least one hour, or overnight for heavy scale buildup.
5. After soak period, turn control to OFF position.
6. Drain hot water from pans. Scrub with a plastic scouring pad. Rinse thoroughly with hot water then dry.
7. Refill tank and resume operation.
8. Heavy scale buildup may require additional treatments.

FIRST AID

EYES: In case of contact, immediately flush with warm water for 15 minutes and a consultant a physician.

SKIN: Wash with soap and water.

INHALATION: Relocate to fresh air.

INGESTION: If swallowed, drink plenty of water or milk and consult a physician.

EMERGENCY PHONE:
(800) 255-3924

IMPORTANT:

Turn selector switch OFF if soaking overnight.